



The 'closed loop' is necessary to maintain the controlled variable at a steady value.
The 'open loop' increases speed of response.

Figure 1: A. HARDY's «proportional» thermostat. B. The components of a feedback control system.